



INSTRUCTIONS FOR USE GLASS AND CERAMIC PRODUCTS

DEAR CUSTOMER,

Thank you for your interest in our offer and congratulations on your choice. You have acquired a product produced by Glasmark. Our company's philosophy is to follow the latest global trends and provide customers with products with a unique character and interesting style.

CAUTION

The manual contains important information on the use and maintenance of glass and ceramic products. Please read these simple instructions carefully and follow them in order to achieve excellent results. Please also keep the following manual in a safe place as it may have been consulted.

The manufacturer is not responsible for any damage to property or persons resulting from improper use.

INSTRUCTIONS FOR USE OF GLASS AND CERAMIC PRODUCTS:

- The product is intended for contact with food.
- Children should not use glassware without adult supervision.
- Do not heat products to a temperature above 60 degrees Celsius. C, e.g. by pouring in hot liquid.
- Rapid heating and then cooling, which will cause a temperature difference of approx. 30 degrees Celsius can cause glass product breakage.
- When washing the dishes in the dishwasher, set the program for glass washing and use the appropriate chemicals.

