



## INSTRUCTIONS FOR USE - WOODEN PRODUCTS

### DEAR CUSTOMER,

Thank you for your interest in our offer and congratulations on your choice. You have acquired a beech wood base with a glass dome. Our product has been designed and made to meet your expectations and will certainly be an integral part of a modern kitchen.

### CAUTION

The manual contains important information on the use and maintenance of a wooden base, please read these simple instructions carefully and follow them in order to achieve excellent results. Please also keep the following manual in a safe place as it may have been consulted.

The manufacturer is not responsible for any damage to property or persons resulting from improper use.

### INSTRUCTIONS FOR USE OF THE WOODEN BASE:

- The product is intended for contact with food.
- Use away from heat sources and protect against sunlight.
- Do not wash under running water, by immersion or in a dishwasher.
- Contact with moisture increases the risk of warping and cracking.
- Use only dry or damp cloth for cleaning.
- A natural property of wood in contact with water is the formation of a rough, rough surface.
- Do not use detergents or chemical furniture care agents.
- Maintenance consists in oiling the wood with kitchen oil using a cloth.
- Oiling should be done at least once a month. Olive oil is not recommended because it is sticky.

**The product is covered by a one-year warranty, subject to the above conditions.**

